

ГАЙКОВЕРТЫ ГИДРАВЛИЧЕСКИЕ СЕРИЯ PSD



Архангельск (8182)63-90-72	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Ижевск (3412)26-03-58	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Киров (8332)68-02-04	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Краснодар (861)203-40-90	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Красноярск (391)204-63-61	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Курск (4712)77-13-04	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Липецк (4742)52-20-81				

Россия (495)268-04-70 Киргизия (996)312-96-26-47 Казахстан (772)734-952-31

Единый адрес для всех регионов: www.powermaster.nt-rt.ru || pwo@nt-rt.ru

PSD SERIES SPECIFICATIONS



Simply...


The Most Advanced Wrench Ever Produced

- Faster Stroke!
- Anti-Back Lash Mechanism!
- Hands-Off Operation!
- Less Moving Parts!
- Unique Design to Fit Every Application!
- Accurate Repeatability!

Are only a few of the Improvements that Powermaster has brought to the Industry!

Technical

Model No.		PSD-0.75	PSD-1	PSD-2	PSD-3	PSD-5	PSD-7	PSD-11	PSD-15	PSD-20	PSD-27	PSD-60	PSD-100
Square Drive		3/4"	3/4"	3/4"	1"	1.1/2"	1.1/2"	1.1/2"	2.1/2"	2.1/2"	2.1/2"	2.1/2"	3.1/2"
Min. Torque	Kg-m	10	13	18	45	78	102	162	204	268	375	802	1390
	(Ft/Lbs)	(72)	(94)	(132)	(330)	(565)	(740)	(1,174)	(1,475)	(1,940)	(2,720)	(5,800)	(10,053)
Max. Torque	Kg-m	106	126	183	460	774	1020	1612	2040	2852	3762	8020	13900
	(Ft/Lbs)	(766)	(911)	(1,325)	(3,330)	(5,600)	(7,400)	(11,659)	(14,755)	(20,625)	(27,200)	(58,000)	(100,538)
Output Accuracy		+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%	+/-3%
Repeatability		100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%
Duty Cycle		100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%
Tool Weight	Kgs	1.0	1.25	2.50	4.20	8.40	8.90	13.6	22.0	28.5	32.7	60.8	109
	(Lbs)	(2.20)	(2.75)	(5.80)	(9.30)	(18.60)	(19.60)	(30.00)	(48.50)	(62.70)	(72.00)	(133.70)	(240.00)



Dimensions

Model No.	PSD-0.75		PSD-1		PSD-2		PSD-3		PSD-5		PSD-7		PSD-11		PSD-15		PSD-20		PSD-27		PSD-60		PSD-100	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Height	78	3	88	3.5	105	4.15	135	5.3	163	6.4	182	7.17	198	7.81	232	9.15	237	9.35	259	10.2	292	11.5	349	13.7
Length 1	120	4.75	94	3.7	121	4.76	153	6.02	194	7.62	208	8.2	227	8.95	295	11.6	274	10.8	294	11.6	367	14.5	469	18.5
Length 2	91.5	3.6	123	4.8	160	6.3	213	8.38	254	10	291	11.5	313	12.3	373	14.7	390	15.3	415	16.4	522	20.6	619	24.4
Radius	18.7	0.74	20	0.78	25	0.98	33	1.28	41	1.62	45	1.78	50	1.96	58.7	2.3	58	2.29	63	2.46	79	3.1	95	3.74
Width 1	40	1.57	42	1.65	51	2.01	67	2.64	82	3.22	92	3.61	100	3.94	100	3.93	124	4.86	134	5.28	167	6.58	200	7.87
Width 2	52.6	2	65	2.55	72	2.81	93	3.67	116	4.55	128	5.05	137	5.38	158	6.2	183	7.19	194	7.65	226	8.9	260	10.3
Width 3	86.7	3.4	87	3.43	118	4.63	149	5.85	175	6.89	204	8.03	225	8.86	252	9.93	275	10.8	293	11.5	372	14.6	412	16.2

Note : All tool weights include Couplers, Swivels, Reaction Arm and Internal Oil.



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Россия (495)268-04-70 Киргизия (996)312-96-26-47 Казахстан (772)734-952-31

Единый адрес для всех регионов: www.powermaster.nt-rt.ru || pwo@nt-rt.ru